

Installation Instructions BM-1 Std, BM-1 Pro Pickups

- 1) The sensing element for the BM-1 series of pickups requires a flat area approximately 1/4" high by 2 1/4" in length on the saddle part of the bridge of the instrument. Check the fit of the element against the bridge. Re-contour or shape the bridge if necessary.
- 2) Remove the strings and tailpiece from the instrument.
- 3) The VHB tape side of the thin metal stand-off will adhere to the underside of the tailpiece. Before attaching the stand-off to the tailpiece, check the fit and trim the stand-off if necessary.
- 4) Remove half of the backing paper from the stand-off and press the stand-off firmly into place on the underside of the tailpiece. The black protective material should be facing downwards toward the instrument top.
- 5) Remove the backing from a 1/4" wide strip of VHB tape and press it into place on the brass face of the sensing element.
- 6) Remove the backing from the VHB tape, position the sensing element over the flattest area of the bridge and firmly press the element into place on the bridge face.
- 7) Reinstall the tailpiece on the instrument
- 8) Reinstall the strings.
- 9) Any excess wire can be stored inside the jack assembly by slowly but firmly pushing it in through the grommet hole in the jack box.

