

NBJA Jack Assembly Installation Instructions

1) The output jack is threaded into the rosewood jack body. Loosen the nut and turn the output jack counter clockwise to remove it from the body.

2) There are two contacts on the output jack. The short contact is the positive (+), and the longer bent contact (soldered to the remainder of the cable clamp) is ground (-). You will need to solder your pickup in accordingly.

3) The banjo jack assembly is secured to the tensioning hooks of the instrument in the same manner that a banjo armrest is attached. The two screws that go through the jack assembly thread into a 2" long aluminum nut that is slid in behind the hooks.

4) The jack assembly is normally placed at about the 4 o'clock position relative to the front of the banjo (when viewed from the front with the neck sticking straight up).

5) Remove one of the two mounting screws that go through the jack body and loosen the other screw almost all the way off.

6) From the end that you've removed the mounting screw, slide the aluminum nut as far as it will go in behind one of the tensioning hooks. Then, when there is clearance for the other end of the aluminum nut, slide the nut part way back so that the nut is behind both hooks.

7) Re-insert the screw that had been removed from the jack body.

8) Position the jack assembly and tighten the two screws to hold the NBJA securely in place.



New Rosewood Bodied Jack Assembly