

### Installation Instructions For The RB Jack Bracket

This bracket is designed to mount the output jack provided with RB-1 and RB-2 passive model bass pickups to the back side of a bass tailpiece. The kit contains a mounting bracket, 2 short stainless wood screws and 3 inches of A and B part self adhesive velcro.

#### Installation with velcro

Tools required: 12mm wrench, rubbing alcohol.

- 1) Choose an area where you'd like to mount the bracket for the output jack. This area should be as flat as possible so that the bracket and the velcro that will hold it in place will fit properly against the back side of the tailpiece.
- 2) The bracket may be installed either horizontally or vertically relative to the tailpiece. How you align it will depend upon your own preference and the profile of the back of the tailpiece.
- 3) Make sure that area where you will mount the bracket is clean and dry. It is suggested that the area be wiped down with a bit of rubbing alcohol.
- 4) Cut a piece of velcro to match the length and width of the bracket base. Remove the backing from this cut piece and adhere it to the underside of the bracket.
- 5) Adhere the other 3" length of velcro to the area where you want to mount the jack bracket.
- 6) Remove the endpin button from the existing jack assembly, loosen the nut (12mm wrench) holding the jack to the black bracket and re-install the jack into the new jack bracket.
- 7) Press the new jack bracket into place on the velcro pad to complete the installation.



Note: It is suggested that you hold the jack body when plugging in or unplugging from the jack.

#### Installing with wood screws

Tools required: Drill, pencil, 5/64 drill bit, bar soap, phillips head screw driver.

- 1) Choose an area where you'd like to mount the bracket for the output jack. This area should be as flat as possible so that the bracket will fit properly against the back side of the tailpiece.
- 2) The bracket may be installed either horizontally or vertically relative to the tailpiece. How you align it will depend upon your own preference and the profile of the back of the tailpiece.
- 3) Inserting a pencil into the two mounting holes of the bracket, mark the position of the two holes to be drilled into the back of the tailpiece.
- 4) Drill a 5/64" dia. hole to a depth of 1/4" in the center of each of the marks made on the tailpiece.
- 5) Rub the threaded portion of each wood screw on the bar soap. This will lubricate the threads and make it easier to turn in the screws.
- 6) Install the bracket with the wood screws.
- 7) Remove the endpin button from the existing jack assembly, loosen the nut (12mm wrench) holding the jack to the black bracket and re-install the jack into the new jack bracket.

